

6006TLB
Low Profile Twin Size Air Bed
with Flock Top

74" x 38" x 9"

*inflated size may vary

Instruction Manual



Thank you for purchasing a Pure Comfort product. Please read the care, use, and warnings included in this manual in their entirety before inflating or using your air mattress. Always follow these instructions to prolong the life of your air bed and to ensure you have a safe and comfortable experience. Keep this manual with your air mattress for future reference and ensure that guests and others have read this material and understand these instructions before using.

WARNINGS - GENERAL SAFETY INFORMATION

DO NOT DISCARD THIS SHEET - READ AND FOLLOW ALL INSTRUCTIONS AND WARNINGS BEFORE INFLATING OR USING THIS PRODUCT.

⚠ WARNING: This is an electrical product - the air mattress pump is not a toy. To avoid risk of fire, burns, injury or shock:

- PUMP REQUIRES FOUR (4) "D" BATTERIES. BATTERIES NOT INCLUDED.
- Remove batteries from the pump before storing. Never mix old and new batteries or battery types.
- Supervision is required when this product is in use by or near children, invalids and/or disabled persons.
- Never leave the pump unattended while in use, inflating or deflating the mattress. If you notice any unusual performance (noise, vibration, burning smells, etc.) turn off the pump and remove it from its housing immediately. Obtain protective eye cover, open battery door and remove batteries. Do not touch any liquid inside the battery compartment if present, and ensure the batteries are not hot to the touch before grasping.
- This pump is only intended to inflate this specific mattress. Never use this product in any manner other than its intended use as described in these instructions.
- Never attempt to open, repair, or make any adjustments to the pump and/or battery compartment.
- Never use any attachments or nozzle adapters not intended for use with this specific model air bed and pump.
- Never operate the pump if the batteries are corroded, if the battery compartment door is broken or missing, if the pump is not working properly, if it has been dropped or otherwise damaged, or if it has been exposed to water.
- Never operate the pump for an period exceeding 5 minutes of continuous use.
- Keep the pump and battery compartment away from heat sources and open flame.
- Never operate the pump with any of the air openings or vents blocked. **You must remove the safety cap from the pump top before inflating.**
- Keep air inlets free of lint, hair, and similar foreign objects.
- Never operate the pump in the presence of flammable fumes or liquids, or an area where these have recently been present.
- Never insert or place any item or foreign object into any of the openings on this product.



⚠ ADDITIONAL WARNINGS:

- **The Maximum Weight for this bed is 250 LBS / 113 KGS Total.**
- This item is intended for ages 12 and up.
- Do not sit or lie on the mattress during inflation or deflation.
- Make sure that the floor is clear of any items which may puncture or damage the mattress fabric.
- After inflation, a significant increase in temperature may cause the internal air to expand. Air must be released to prevent the bed from failing due to overpressure. A large decrease in temperature will cause air to contract, and additional air may be required. Avoid using this bed in extreme temperatures. Never inflate the bed in near-freezing or below freezing temperatures.
- Keep mattress away from open flames and heaters.
- Do not stand, walk, or jump on the mattress.
- Do not allow children or pets to play on or near the bed.
- Do not smoke on the bed. This furnishing has not been evaluated for flammability or cigarette ignition resistance.
- The mattress is not a life saving device or pool toy. Do not use as a flotation device or as a water toy.
- Never inflate this bed with a hair dryer or air compressor.
- Do not let young children sleep on this mattress until mature enough to sleep in an adult bed. Young children can suffocate, especially in the case of unexpected deflation. Never leave a child or disabled person unattended or sleep on the same mattress as a young child.
- Do not leave the mattress unattended during inflation or deflation. The pump's operation and inflation/deflation process must be monitored by a responsible adult.

INFLATING:

1. Check your surroundings for any sharp objects on the ground/floor that may cause damage to the bed (nails, screws, sharp rocks, etc.).
2. Unfold the bed and lay it flat on the floor.
3. Attach an adaptor nozzle to the Pump and ensure it is in the "OFF" position.
4. Insert 4 NEW "D" batteries into the Pump. (see instructions on reverse side of this sheet)
5. Make sure the pump nozzle vents are clear of any obstructions.
6. Open both outer and inner seals on the inflation valve on the side of the bed as shown in Figure 1.
7. Insert the largest adaptor nozzle tip into the valve on the bed and turn the pump on.
8. Inflate to about 80%. Close one-way inner seal as shown in Figure 2 so that rubber "needle" is showing.
9. Switch to nozzle to middle adaptor and continue inflating. When air mattress reaches the desired firmness, switch the pump off.

DO NOT OVERINFLATE: *If this product rocks back and forth easily when placed on a flat surface, slowly release air until it becomes stable.*



Figure 1



Figure 2

DEFLATING:

1. Fully open the valve on the bed (inner and outer seal) and allow the air to escape.
2. Once almost fully deflated, attach the nozzle adaptor to the "DEFLATE" vent on top of the pump.
3. Turn the pump on to remove the remaining air.
4. Close the valve seals, and carefully fold the bed and place into the storage bag.

NOTE: If you are going to be storing your bed for an extended period of time, make sure to remove the batteries from the pump before doing so.

IMPORTANT: ADDITIONAL INFORMATION REGARDING INFLATION PRACTICES, PUMP USE, PUMP SAFETY, AND USING THE REPAIR KIT ARE LOCATED ON THE REVERSE SIDE OF THIS SHEET.

FULLY READ THIS INFORMATION BEFORE USING THIS PRODUCT.

CUSTOMER SERVICE:
E-mail: customerservice@puregbi.com
Toll-Free Phone: 866-498-5269 (9am-5pm, M-F)
Pure Global Brands, Inc. West Palm Beach, FL 33411

Please visit www.pureglobalbrands.com and register your product to ensure warranty coverage and for any important safety or product updates. Use search word: 6006TLB.

PUMP INSTRUCTIONS:

Battery Pump Requires 4 “D” Batteries. (not included). Before inserting the batteries, always ensure the Pump is in the “OFF” or “O” position.

1. Open the battery cover by releasing the clasp on the side of the pump.
2. Insert 4 new “D” batteries, making sure to orient the batteries properly to the “+” and “-” markings printed at the bottom of the battery chamber.
3. Close the cover on the pump, making sure that the battery terminals contact the metal plates on the inside of the cover.
4. Place the locking wire over the lock housing on the cover, and press down on the lever to lock the cover into place.

CARE AND MAINTENANCE:

1. Inspect your bed prior to each use. Check the pump, pump housing and battery compartment for any damage, foreign objects or battery corrosion.
2. Keep your bed away from any sharp items or objects with rough edges. Long tears and large holes may not be repairable, and may not be covered under your warranty.
3. Do not let the flocked top of your mattress become wet. Repeated exposure to liquids will damage the flock material and will not be covered under your warranty.
4. To clean the PVC sides and bottom of your mattress, apply a mild solution of warm water and gentle cleanser (such as dish washing liquid) with a towel. Do not immerse your bed in water or use a hose, as this will damage the bed. Always allow to fully dry before use.
5. Do not store your bed outside or where it will be exposed to extreme temperatures and/or humidity.
6. Do not store your bed in direct sunlight.
7. Do not inflate this bed in near-freezing or below temperatures.

REPAIR KIT USE:

1. Locate the leak. For small, hard-to-find leaks, inflate the bed and spray the suspected location of a leak with water. Look for air bubbles indicating the leak source. Once found, mark this spot with chalk or a piece of tape. DEFLATE the air bed.
2. Clean the affected area with soap and water, rinse thoroughly and allow to fully dry. Cut a piece of patch material that will fully cover the puncture. Apply the self-adhesive patch to the leak by peeling off the backing and placing it sticky side down on the air bed. Rub patch to ensure adhesion. Allow (4) Four hours for the repair to set before attempting to inflate the air bed. Long or large tears may not be able to be repaired.

AIR MATTRESS INFLATION PRACTICES:

The air bed material may stretch during use and the mattress may need additional air over a period of time. The air inside of the bed may expand and contract with varying temperatures and conditions. To extend the life of this product, never unfold or inflate the air bed in temperatures below freezing, avoid prolonged exposure to the sun, and protect from contact with rough ground. If, after inflation, this product rocks back and forth easily while on flat ground, it is advised that a small amount of air be released to prevent failure from overpressure when weight is applied to the mattress.

AIR MATTRESS PUMP USE PRACTICES:

-CAUTION: RISK OF ELECTRIC SHOCK. DO NOT USE IN WET OR RAINY CONDITIONS AND EXERCISE CAUTION NEAR WATER SOURCES. NEVER EXPOSE PUMP DIRECTLY TO WATER OR LIQUIDS.

- NEVER expose the pump to heat sources or open flame.
- DO NOT run this pump for longer than 5 Minutes at a time. Failure to do so may cause the unit to overheat, present a fire hazard, and will diminish the lifespan of the unit.
- DO NOT allow children to use or play with the pump.
- DO NOT attempt to open the pump housing or perform repairs to this pump.
- DO NOT use this pump if the plastic housing is cracked or otherwise damaged or if the pump has been exposed to water or open flame.
- ENSURE you have fully read and understand the electrical warnings on the opposite side of this sheet.

LIMITED WARRANTY

Pure Global Brands, Inc. warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of 90 DAYS FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the Company.

All warranty coverage extends only to the original retail purchaser from the date of purchase. Pure Comfort's™ obligation under this Warranty is limited to replacing or repairing, at Pure Comfort's™ option, the product at one of its authorized service centers. All products for which a warranty claim is made must be received by Pure Comfort™ at one of its authorized service centers and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Pure Comfort™. All warranty claims must be pre-authorized by Pure Comfort™. Pre-authorization can be obtained by calling 866-498-5269. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, or repairs not provided by a Pure Comfort™ authorized service center or for products used for commercial or rental purposes. This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of Nature (such as damage caused by wind, lightning, snow, water, or ice). Weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other Warranty beyond that specifically set forth above is authorized by Pure Comfort™.

PURE COMFORT™ IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND PURE COMFORT™ SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights. You may also have other rights, which vary from state to state